Concrete Joints, Cracks & Repairs: Understanding Floor Treatments

TECHNICAL GUIDE 04 | JOINT FILLING, CRACK REPAIR & PATCHING

Understanding Concrete Floor Joints

Concrete shrinks as it dries and responds to moisture and temperature changes. Control and construction joints are intentional features of a slab; cracks and surface damage may develop for other reasons. Each condition requires evaluation before selecting a treatment.

Semi-rigid fillers, flexible urethane sealants, crack repair materials and cementitious patching products perform different functions. Selecting the right approach depends on movement, traffic, the condition of the concrete and the intended finished floor.

01 | Joint Types and Filling Needs

Control (contraction) joints

Saw-cut or formed control joints create a planned location for shrinkage-related cracking. The joint may widen as the slab continues to shrink.

Construction joints

Construction joints occur where separate concrete placements meet. Their design may include load-transfer devices; the joint treatment does not replace those structural details.


Isolation joints

Isolation joints are intentional separations between a concrete slab and adjoining structures, such as columns, walls, foundations, or equipment bases. Unlike control joints, which help manage shrinkage cracking, isolation joints allow the slab and adjacent structures to move independently without transferring stress between them.

Expansion joints

Expansion joints are intentional separations in concrete slabs designed to accommodate movement caused by temperature changes, expansion, contraction, and other structural conditions.

CONCRAFTED



Fill or Honor?

Hard wheels crossing an unsupported joint can damage the concrete edges, a condition known as spalling. Open joints also collect debris. Filling joints can protect the concrete from these issues but **sometimes honoring the joint so the concrete can move is the best option.**

Joint	Fill Recommendation
Control	Honor or Semi Rigid
Isolation	Honor or Urethane Caulk
Construction	Honor or Urethane Caulk
Isolation	Honor or Urethane Caulk

02 | Semi-rigid joint fillers

Semi-rigid epoxy and polyurea fillers are primarily intended to support and protect joint edges under hard-wheeled traffic. They are often installed flush with the concrete surface in warehouses, manufacturing facilities and distribution spaces.

Semi-rigid epoxy

Semi-rigid epoxy offers firm joint-edge support and is commonly specified for industrial slab joints. Its cure time and suitability depend on the specific product and jobsite conditions.

Semi-rigid polyurea

Semi-rigid polyurea provides a similar edge-protection function, often with a faster cure. Product formulations vary, including temperature suitability and color stability.

“Semi-rigid” does not mean a joint can open indefinitely without affecting the filler. These materials are chosen for edge support, not for accommodating substantial movement.

03 | Flexible Urethane Sealants

Flexible polyurethane joint sealants, often called urethane caulk, are selected when movement accommodation and limiting entry of water or debris are important.

Flexible sealants generally do not provide the same edge support as semi-rigid fillers under frequent hard-wheeled traffic. Conversely, semi-rigid fillers should not be substituted for movement-rated sealants in expansion or isolation joints.

04 | Why timing and shrinkage matter

Concrete can continue shrinking after the joint has been filled. As joint walls move apart, a semi-rigid filler may separate from one or both sides. This can occur even when the original installation was appropriate.

When should joints be filled?

Industry guidance generally favors waiting as long as practical before installing semi-rigid filler, allowing more initial shrinkage to occur. A waiting period of approximately 30–90 days is often discussed for conventional new slabs when schedules permit, but it is not a universal requirement. Product guidance, slab conditions and the construction schedule govern.

What if separation develops?

Small gaps may need monitoring or later maintenance, especially where wheeled traffic is frequent. A gap alone does not establish that installation was defective; the extent of movement, original joint condition and service demands matter.

05 | Preparation of Joints

Joint walls must be sound and prepared according to the selected manufacturer’s instructions. Dust, curing compounds, coatings, debris, oils or moisture can interfere with bonding. Usually, joints are traced with a saw to clean edges and remove debris.

Semi-rigid fillers and flexible sealants require different depths and configurations. Flexible sealants may require backer rod or bond-breaker materials to control depth and prevent three-sided adhesion. Semi-rigid fillers used for industrial traffic are typically installed to provide edge support at the upper joint.

06 | Understanding concrete cracks

Cracks may result from shrinkage, restraint, settlement, loading or other conditions. Before filling, determine whether the crack is stable or active and whether there is vertical displacement or another sign that additional evaluation is needed.

CONCRAFTED

Stable versus moving cracks

A relatively stable, nonstructural crack may be suitable for a compatible rigid or semi-rigid repair material. There is always the opportunity for a crack to continue to move and grow as it is typically a symptom of greater slab movement. Excessive cracking may require evaluation by a qualified engineer; cosmetic filling does not correct the underlying cause.

Cracks Visibility

On polished concrete, a filled crack remains visible and may differ in color and texture from the surrounding slab. Sometimes it may be better not fill fine cracks as to not draw additional attention to them. Under resinous coatings, crack repairs can be concealed more effectively, but future movement may still cause the crack to telegraph through the coating. The final appearance and performance depend on the crack, repair material and flooring system.

07 | Repairing damaged or missing concrete

Spalls, trenches, divots, damaged edges and deteriorated concrete may require more than a narrow crack filler. Larger repairs often involve removing unsound material, preparing the substrate and installing a compatible repair mortar or topping. Repair depth, cure time, bond, traffic and finished appearance all matter.

Repairs beneath resinous coatings

Where the floor will receive a resinous system, repair materials are selected for soundness, bond, dimensional stability and compatibility with the planned surface preparation and coating. Concrafted uses repair products from manufacturers such as Rapidset, ARDEX or similar manufacturers depending on the specific condition and system. A repair must be ready for coating under the applicable manufacturer requirements.

Repairs in polished concrete

Where the repair remains exposed, polish-ability and appearance become especially important. Concrafted may consider polishable cementitious products such as TRU PC for appropriate larger repairs or resurfacing work. Even a polishable repair may not match the original slab in aggregate, color, sheen or age; a mockup can help establish expectations.

References & further reading

American Concrete Institute — ACI 302.1R, Guide to Concrete Floor and Slab Construction (industry guidance on floor joints and filling).

This guide is general educational information. Product specifications, structural conditions, movement, traffic, substrate condition and finished flooring requirements must be evaluated for each project.

Metzger/McGuire — Technical bulletins and product literature on semi-rigid epoxy and polyurea fillers, joint filling details, timing and shrinkage-related separation.

metzgermcguire.com